

### **FRONT SPROCKET MOUNTING TAB**

Gates Carbon Drive recommends mounting 4 or 5 bolt front sprockets on a crankarm with a mounting tab/shelf for the sprocket. Tabs can be located on either side of the crankarm to achieve proper belt line.

*Figure 1: Recommended mounting tab on a 5-bolt crank arm.*

